

WARNING:

The product is for people who include and over 14 years old. Kids should assemble under the guidance of adults.


MAINTENANCE:

- 1. Keep the product away from the source of ignition and water to prevent any damage.
- 2. Don't use chemical reagents like alcohol, ammonia water to clean the product.
- 3. Use clean and soft fabric to clean the product if necessary.

ATTENTION



- 1. Take off the pieces from the board according to each step before assembling, and place them properly in case of missing.
- 2.According to the instructions when you assemble all the pieces. **Keep properly the instructions and validated after assembly.**
- 3. Polish the parts with sand paper, **enhance aesthetic feeling** and gear lubrication.
- 4. Repair with glue prepared by yourself if the wooden pieces would be break.
- 5. There are letters on some parts as shown, assemble them together with same letters.
- 6. Scan the **QR code** with remind for assembly video.
- 7. There is a little different from several parts and the pictures on instruction, **subject to parts number.**
- 8. There are **spare parts** on wooden board.



Product Display

*CUSTOMER SERVICE

ROKR Facebook: @rokrofficial Email: service@robotime.com

Please contact us on Facebook or email if you have any questions.

FAQ:

Problem	Cause	Solution						
1.The motorcycle does not run smoothly.	1.The rubber ring is not inserted in the correct position. 2.The transmission parts were not sanded or waxed.	 1.When turning the metal key clockwise, if the knob rotates smoothly, observe whether the rear wheel rotates with the knob. If the rear wheel does not rotate, turn the motorcycle over and adjust the rubber ring to the correct position with the small screwdrive. 2.Observe the up and down movement of the piston. If the piston does not move smoothly, observe whether the steel shaft under the piston and the shaft sleeve interfere with other wooden boards. If there is interference, it can be adjusted with a screwdriver. 						
1.Motorcycles cannot travel in a straight line. 1.The front of the motorcycle is not aligned 2.The motorcycle body is not righted. 3.Uneven ground.		1.Refer to page 29 to adjust the direction of the motorcycle. 2.Refer to page 30 to confirm whether the driving steps are correct. 3.Select a flat groundSelect a flat ground.						

(Suggest to put all the parts in a box to prevent loss.) Parts list

Item	Spring	Socket head cap screw	Socket head cap screw	Socket head cap screw	Hexagon nut	Screw	Screw	Screw	Black Screw	Black rubber ring	Black rubber ring	White silicone rubber ring
Item number	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12
Illustration		6mm M3*6	12mm M3*12	35mm 35mm M3*35		16mm	6mm M2*6	6mm M1.4*6	5mm M2*5	ø34*2	ø55*2	Ø15*2
Quantity	1	3	3	1	1	10	17	8	8	1	1	2

Item	Shaft sleeve	Steel shaft	Steel shaft	Steel shaft	Steel shaft	Acrylic plate	Tension spring	Square shaft	Metal key	Screwdriver	Hexagon wrench	Small screwdriver
Item number	P13	P14	P15	P16	P17	P18	P19	P20	P21	P22	P23	P24
Illustration	©	15mm	25mm	35mm	45mm		Anthund	2.01	U	Market		
Quantity	14	2	2	2	1	2	2	1	1	1	1	1

Item	Wind deflector	Hinge	Screw	Spring	Wax			
Item number	P25	P26	P27	P28	P29			
Illustration			•					
Quantity	1	4	16	2	1			






Polish the gray parts with sandpaper.



Perspective changed.



Step 1





Wax the gray parts with remind.



Step 2



Ensure the. connection of gears smoothly.

connection of parts running smoothly.

Ensure the



Complete 2 same parts.




Printed side





Assemble the parts symmetrically.





Blank side















































































Standing mode,


Support the side support and freely adjust the front direction.




Driving mode, it is not suitable for rough roads such as gravel road, carpet floor and so on.




It can be rotated 6-7 times, otherwise the tool is easy to be damaged.)




2.Confirm that the front and body are in the same line.



3. Hold the motorcycle body, the main support frame lands on the ground, and press the motorcycle body obliquely behind.



4. The main support frame bounces forward. (Make sure the rear wheels land before the main support frame bounces up, otherwise they will spin)



5. Release your hand and let the motorcycle move forward.







Find us on Facebook & Youtube.

Visit www.robotime.com for more new designs.