

AIRPLANE-CONTROL TOWER

MECHANICAL MUSIC BOX

ROKR

AMK41

WARNING:

The product is for people who include and over 14 years old.
Kids should assemble under the guidance of adults.

MAINTENANCE:

Keep the product away from the source of ignition and don't soak it into water.
Don't use chemical solvent like alcohol, ammonium hydroxide or cleaning agent to clean the product.
Use clean and soft fabric to clean the product. Polish the part edge with sandpaper.

Email: service@robotime.com



ROKR Facebook



store.robotime.com



Special attention in assembly.



Ensure the connection of gears running smoothly.



Wax the gray parts with remind.



Polish the parts with sandpaper.



Complete 2 same parts.



Printed side



Blank side



Step1



Step2



Perspective conversion.

Parts List *Due to customs policy in international shipping, the wax and glue may not be included. Please prepare them yourself.

Item	Movement	Screwdriver	Screw	T-Key	Metal Gasket	Square Shaft Sleeve	Black Shaft Sleeve	Steel Shaft	Steel Shaft	Wax	Sandpaper	Crevice Tool
Number	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12
Illustration												
Quantity	1	1	7	1	1	4	4	4	6	1	1	1



