

NOTICE:
Children should be accompanied by adults while assembling.
Please keep the product away from flammable substances and humid environments to prevent damage.
The instruction must be retained since it contains important information.

MAINTENANCE:
Please clean the product with clean soft cloth, and sand the board lightly with sandpaper.
Don't use chemical reagents like alcohol and ammonia water to clean the product.

ATTENTION TO THE MOVEMENT:
The movement is precise and please do not drop or collide it.
Do not apply too much force when winding up.
Do not touch the movement roller with your fingers to avoid finger injury.

Email: service@robotime.com




www.robotime.com



store.robotime.com

- Perspective changed
- Flip to assemble
- Wax the yellow parts
- Ensure that the gears connect smoothly
- Part P18 in Bag No. 1
- U9 means the part has spare ones
- Remove protective film

- Special attention in assembly
- Printed side
- Blank side
- Step 1
- Step 2
- Complete 2 same parts

Part List		Bag No. 1										Bag No. 2							
Name	Movement	T-shaped key	Big mushroom knob	Little mushroom knob	Black screw	Screw	Partially threaded screw	Steel shaft	Screwdriver	Metal plug	Bronze screw	Bronze screw	Shaft sleeve	Gap tool	Ratchet 1	Ratchet 2	Acrylic	Wax	
Item Number		P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12	P13	P14	P15	P16	P17	P18	
Picture																			
Quantity	1	1	1	1	5	7	1	3	1	1	10	26	14	1	1	1	1	1	

