


MECHMIX

ROKR

CGL04 Beacon Tower



ASSEMBLY INSTRUCTION



BEACON TOWER

- WARNING:**
- This product is powered by USB connection and does not contain Type-C power cable, which must be provided by yourself (input: 5V $\pm$ 0.1A).
 - Not suitable for children under 3 years old.
 - The product shall only be used with a transformer for product or a power supply for it.
 - The product shall be used with the power supply supplied, if the transformer is supplied with the product.
 - The transformer or power supply is not a toy or model.
 - Misuse of transformer can cause electrical shock.
 - The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
 - Do not connect the wire to output socket!
 - The product is not to be connected to more than the recommended number of power supplies.
 - If the product contains motor, motor may be a hot component. Do not touch it to avoid burns while operating.
 - This product is only to be connected to equipment bearing either of the following symbols: or .
 - This product does not need liquid cleaning, and please clean the product with clean soft cloth.
 - This product contains functional edges and points that are sharp and hazardous. To prevent puncture injuries, adult supervision is required.
 - The instruction must be retained since it contains important information.

- NOTICE:**
- Children should be accompanied by adults while assembling.
 - The product contains small parts and electronic components. Adults should guide and supervise children in the correct use of the product to prevent ingestion or choking.
 - Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
 - Take off the pieces from the board according to each step before assembling and place them properly in case of missing.
 - Please install the electronic components correctly and test whether the circuit is normal after completion.
 - Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
 - Please clean the product with clean soft cloth, and sand the board but lightly with sandpaper.
 - Please keep the product away from flammable substances and humid environments to prevent damage.

Instructions of using the nail clipper

When cutting, make sure the nail clipper fit tightly to the parts.

Cut leftover cutting points

Icon Illustration

Part P20 in Bag No. 3

Special attention in assembly

Perspective changed

Cut leftover cutting points

Assembly tips

Step 1

Step 2

Complete 2 same parts

1

Completion

When cutting, make sure the nail clipper fit tightly to the parts.

Scan for assembling videos

1

Grease the yellow side with cotton swabs

Use a screwdriver to assist in assembly

1

Complete 8 same parts

Scan for assembling videos

Keep both pistons level

1

Use a screwdriver to assist in assembly

1

1

1

1

Move the piston into the cylinder

Use a screwdriver to assist in assembly

2

Grease with cotton swabs on the yellow parts

2

Note the size of the positioning column.

Rotate the worm gear to ensure the assembly is assembled correctly.

3

Check that the wires are properly secured.

3

Align the notch, and wiggle it to insert.

4

Pay attention to the wire position.

4

Do not leave any gaps during assembly

Rotate the worm gear to ensure the assembly is assembled correctly.

Scan for assembling videos

5

5

Pay attention to the wire position.

Use a screwdriver to assist in assembly

5

Grease the yellow side with cotton swabs.

Align the notch, and wiggle it to insert.

5

5

5

5

5

5

5

5

5

