


GRAVITY SWING

Santa on Sleigh

MCD05 / 141 PCS

ROKR



WARNING:

- Children must assemble under the guidance of adults.
- The product contains small parts. Adults should guide and supervise children in the correct use of the product to prevent ingestion or choking.
- The instruction must be retained since it contains important information.

NOTICE:

- Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
- Take off the pieces from the board according to each step before assembling and place them properly in case of missing.
- Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please clean the product with clean soft cloth, and sand the board burr lightly with sandpaper.
- Please keep the product away from substances flammable and humid environments to prevent damage.



store.robotime.com



www.robotime.com

- Special attention in assembly
- Step 1
- Printed side
- Complete 2 same parts

- Perspective changed
- Step 2
- Blank side
- "U9+" means the part has spare ones

Number	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10
Item	Steel ball	Steel shaft	Steel shaft	Shaft sleeve	Counter weight	Bell	Silicone sticker	Support rod	Hook	Wire
Illustration										
Quantity	1	2	1	6	2	2	1	2	1	1

1

2

3

4

Instruction: Turn the gears and the snowflake board will be rotated.

a

a

B1

C4

D3

P8

P7

C28

E4

D13

D14

C1

D12

B5

C10

B10

C9

E5

E6

P1

P2

P4

D16

B3

B4

C14

C11

C13

B15

b

