


GRAVITY SWING

MCD06 / 186 PCS

ROKR

❖ Santa on Skis ❖



Perspective changed

WARNING:

- Children must assemble under the guidance of adults.
- The product contains small parts. Adults should guide and supervise children in the correct use of the product to prevent ingestion or choking.
- The instruction must be retained since it contains important information.

NOTICE:

- Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
- Take off the pieces from the board according to each step before assembling and place them properly in case of missing.
- Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- Please clean the product with clean soft cloth, and sand the board burr lightly with sandpaper.
- Please keep the product away from substances flammable and humid environments to prevent damage.



store.robotime.com



www.robotime.com



Special attention in assembly



Step 1



Printed side



Complete 2 same parts



Polish the parts with sandpaper



Step 2



Blank side



"+" means the part has spare ones

Number	P1	P2	P3	P4	P5	P6
Item	Steel ball	Steel shaft	Counter weight	Silicone sticker	Support rod	Hook
Illustration						
Quantity	1	1	2	1	2	1

1

Instruction: Turn the gears and the snowflake board will be rotated.

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

a

B1

C1

C14

P5

P4

C3

C23

C8

C15

C13

3

F19

F20

F23

E5

D1

B13

C13x4

D2

D4

D3

F3

D27

B9

B10

Complete 2 same parts x2

Pay attention to the direction

Be careful when assembling this fragile part.

Be careful when assembling this fragile part.

