**MECHANICAL MUSIC BOX** 

- The product is for people who include and over 14 years old. Kids should assemble under the guidance of adults.
- The instruction book contains important information. Please keep it well for later use. MAINTENANCE:
- Keep the product away from the source of ignition and water to prevent any damage.
  Don't use chemical reagents like alcohol, ammonia water to clean the product.
  Use clean and soft fabric to clean the product if necessary.
- ATTENTION TO THE MOVEMENT:
- The movement is precise, please do not drop or collide it.

Hagic Piano

- Do not apply too much force when winding up.
- Do not touch the movement roller with your fingers to avoid finger injury.
- Tel: 400-960-0062

57		Special attention in assembly		Flip to assemble	国教院教育国 2003年20
		Ensure the connection of gears smoothly		Printed side	
		Wax the gray parts		Blank side	BOKB Facebook
		Polish the part with sandpaper		Force point of	ROKR Facebook
	(	Ensure the connection of parts running smoothly.		removing pieces	回線階級国
		Assembly tips	1	Step 1	
	( <u>2</u> )	Complete 2 same parts  Complete 6 same parts	2	Step 2	
		2 same parts 0 same parts			store robotime com

ROKR

ı	art List (Due to customs policy in international shipping, the wax and glue may not be included. Please prepare them yourself.)										store.robotime.com					
	Name	Movement	Round Metal Part	Key	Hobnail	Hinge	Pan-head Screw	Flat head Screw	Steel Shaft	Steel Shaft	Steel Shaft	Steel Shaft	Wax	Shaft Sleeve	Screwdriver	Screwdriver
	Item Number	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11	P12	P13	P14	P15
C	Picture				∏_4MM M1.4*4	E.B.	₩ 18 × 8	₩ <u>14</u> MM M3*4	15ММ	20MM	25MM	80MM		0		
	Quantity	1	1	1	8	2	6	5	3	1	3	1	1	16	1	1







