SUPER CREATOR | SUPER STORE! GOLDEN WHEAT BAKERY

01 Notice

⚠ WARNING

- Please read the instructions for power kit.
- The provided transformer is used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is damaged, please replace it.
- If an installation of a power supply is not a toy, it is "⚠".
- Misuse of transformer can cause electrical shock.
- Do not use the transformer if the cord is damaged, the supply examined for damage to the power cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until properly repaired.
- Do not connect the wire to the output socket.
- Do not operate with it in a manner more than the recommended number of times/ usage.
- This product doesn't take "⚠ on cleaning, and please clean it with clean soft cloth.
- Please keep packaging, useful information, fasteners and small items, ⚠ parts for assembly storage.
- Please read the following carefully for more important information.

02 Icon

Please fix parts as shown in case of any parts loosening.

- Two-sided adhesive tape
- Thin double-sided adhesive tape
- Instant adhesive in assembly
- Perspective changed
- Step 1
- Step 2
- Force point

03 Switch box instructions


Power on suggestions:
Plug the transformer into Type-C cable to connect to an external power supply, and then turn on the power switch.
Turn on the switch when the product is connected to an external "Lock-in" power supply, and then plug the transformer into the wall socket