Rolife

Leisure Time Tea Room

DG171

Pictures for reference only. Please subject to our existing products.

Assembly tips

Put small parts into the bag to prevent loss.



Remove the part by pressing its back to reduce burrs.



Polish the edges with sandpaper if there are burrs on pieces or it' s hard to insert.

Tips of assembling

1. All the dimension in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with Ⓟ)



Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.

Tools required

(The right of the arrow " » " corresponds with the tool icon.)

① Sandpaper (Bag No. 1)
② Double-sided tape (Bag No. 1)
③ Tweezers (Bag No. 4)
④ Screwdriver (Bag No.4)
⑤ (Self-preparation) Scissors





































Self-prepare "AAA/LR03/AM4 1.5V" batteries.

What if the light can't work?

1. Check if the switch of the battery box is on.
2. Check if the battery box is correctly installed.
3. Check if the wire connection accords with the instructions.

The switch faces outside.

Collect.





























Completion



MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA