Rolife

Fluffy Cat Bakery

— DP001 —



Pictures for reference only. Please refer to the forming products.

Assembly tips



Put small parts into the bag to prevent loss.



Remove the part by pressing its back to reduce burrs.



Polish the edges with sandpaper if there are burrs on piece or it 's hard to insert.

Tips of assembling

1. All the dimensions in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with ⓟ)



Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.



Tools required

(The right of the arrow " = " corresponds with the tool icon.)



Sandpaper



Double-sided tape



Tweezers



Screwdriver



Scissors





Knife

Shelf

Material list:









Counter

Material list:






Picture Frame

Material list:








Outdoor chair

Material list:



Sign


Material list:

Wall A

Material list:

Wall B


Material list:



N24
Canopy
Material list:
Paper-cutting
DP001-M
M3
S


Box
Material list:
Paper-cutting
DP001-K
K5
K6
K7
Box A
Box B
Box C
Bag
Material list:
Paper-cutting
DP001-K
K8



Transparent cabinet
Material list:
Board
1 DP001
DP001-B:
B4
Paper-cutting
DP001-K
K3
K4
DP001-N
N11
N16
Other parts
4 DP001
P13
P14
P15
P16
P17
P18
1
P15
P16
K4
S
P14
2
K3
S
P17
P13
S
P18
N11
B4
S
N16
Bread
Material list:
Other parts
3 DP001
P10
P11
4 DP001
P26
P12
Paper-cutting
DP001-N
N19
N6
P26
P11


P10
1:1
N6
Bread A
P12
N19
Complete in the same way.
Bread B
Jam
Material list:
Paper-cutting
DP001-N
N12
N13
N14
Other parts
4 DP001
P19
P20
P21
P19
P20
N13
N12
S
P21
N14
Plant
Material list:
Board
1 DP001
DP001-B:
B6
B7
B8
Other parts
4 DP001
P22
P23
B7
B6
B8


P23
M
P22
Light
Material list:
Board
1 DP001
DP001-C:
C6
DP001-F:
F1
2 DP001
Y16
Y12
Y13
Other parts
3 DP001
P4
P6
P5
P7
P4
P7
P6
P5
F1


C6
Wrap it around 12 times.
Y12
Y16
Y16
Y13



Part A
Box A
M
Box B
1
G3
S
4
P25
M
Frame
Material list:
Board
1 DP001
DP001-A:
A5
DP001-C:
C5
DP001-G:
G1
G2
DP001-B:
B1
G4
G5
G6



Board
1 DP001
Y8
2 DP001
Y18
Paper-cutting
DP001-K
K2
DP001-M
M4
DP001-N
N10
N15
N17
N18
N20
N21
N25
N26
N27
N22
N23
Other parts
4 DP001
P24
G4
G6
G5
N23
N22
G1
Y8
2
1
M4
N15



N25
N26
Counter
K2
Part A
Wall A
Wall B



N23
F7
1
2
Outdoor chair
Transparent cabinet
N17
N18


To clearly display the placement position, the illustration will hide part of the X-axis.
Box1
N28
P29
Wood B
N27
Sign
Tip



Assembly sequence
1
N30
N31
3
Self-prepare "AAA/LR03/AM-3.5V" batteries.
Touch Tail Light to on
What if the light can't work?
1. Check if the terminal connections are in place.
2. Check if the battery box is correctly installed.
3. Check if the wire connection accords with the instructions.


P27
F3
How to remove the battery box?


K1
M1


P28
Canopy
M2
N32


BAKERY
Plant







Completion



Series



Fluffy Cat Bakery

DP001



Sweet Scoopery Ice Cream

DP002



Daily Fresh Flower

DP003



Old Times Bookstore

DP004

MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA

49.1DP001.100