DW022

SUPER CREATOR | SUPER STORE | Night Out Food Stall

The picture is for reference only.

Assembly Tips



Remove the tape from the side with the tip of the tweezers.

Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.

Push upwards with the tip of the tweezers to remove the floor.

Use the end of the tweezers to remove the connecting nail or assemble small parts.

01 Notice

⚠ WARNING

- Not suitable for children under 3 years old.
- The product shall only be used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is supplied with the product.
- The transformer or power supply is not a toy or model.
- Misuse of transformer can cause electrical shock.
- The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- This product is only to be connected to equipment of Class Ⅱ. ▣
- Do not connect the wire to the output socket.
- The product is not to be connected to more than the recommended number of power supplies.
- This product doesn't need liquid cleaning, and please clean it with clean soft cloth.
- Please keep the product away from substances flammable and humid environments to prevent damage.
- The instruction must be retained since it contains important information.

02 Icon

Please secure parts as shown in case of any parts loosening:

- Use double-sided adhesive dot
- Use long-strip adhesive tape
- ❗ Special attention in assembly
- Perspective changed
- ① Step 1
- ② Step 2
- Force point

03 Switch box instructions (P2)



① Switch

Touch switch
(Long press to adjust the brightness.)

② Power on

Type-C interface
Attention! Input power: 5V ⎓ 500mA

04 Data cable instructions (P1)



① Connect to power

Self-preparation

② Multi-house play

05 Assembling steps















Assemble in the same way.













06 Add some other tricks



01 Ceiling light assembly

(Light part)

Under the roof for 1 house

D

Purchase it separately

Under the floor for 2 or more houses

(Connecting part)



Cable in the box

Input power: 5V ⎓ 500mA

02 Dust-proof door assembly

C

Purchase it separately

03 Expand your house kit

MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

49.1DW022.100