

DWS03B




SUPER CREATOR | **MINI SUPER STORE** | Butter Bakery House


The picture is for reference only.



Assembly Tips



Remove the tape from the side with the tip of the tweezers.



Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.

01 Notice



WARNING:





- The product contains small parts. Adults should guide and supervise children in the correct use of the product to prevent ingestion or choking.
- The product is a model not food. Do not put into the mouth to avoid ingestion and choking.
- Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
- Please avoid bumping and damaging parts to avoid affecting assembly use.
- Please keep the product away from substances flammable and humid environments to prevent damage.
- Please clean the product with clean soft cloth. Please don't clean this product with chemical cleaners: alcohol, ammonia water, glass cleaner, etc.
- The instruction must be retained since it contains important information.

02 Icon

Please fix parts as shown in case of any parts loosening:

- Use double-sided adhesive dot
- Use strip double-sided adhesive tape
- Special attention in assembly
- Perspective changed
- Step 1
- Step 2
- Force point

03 Assembling steps



04 Add some other tricks

