


Elsa's Tailoring

— DG178 —




Pictures for reference only. Please subject to our existing products.

Assembly tips



Put small parts into the bag to prevent loss.



Remove the part by pressing its back to reduce burrs.




Polish the edges with sandpaper if there are burrs on pieces or it's hard to insert.

Tips of assembling

1. All the dimension in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with (Y))



Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.



Tools required

(The right of the arrow "→" corresponds with the tool icon.)

- 1 Sandpaper
- 2 Double-sided tape
- 3 Tweezers
- 4 Screwdriver
- 5 (Self-preparation) Scissors
- 6 (Self-preparation) Knife

01

Hat rack

Material list:

Board

2 DG178

V1 V2

Bust form stand

Material list:

Board

2 DG178

V3 V4

Ribbon holder

Material list:

Board

1 DG178-D

D6 D7

V5 V6 V7 V8

Paper-cutting


DG178-M

M4


Other parts

4 DG178


P49 P50 P51 P52



02




03




04




05




06




07



08




09



10




11



12



13



14

Material list:

Board

1 DG178-A:

DG178-C:

Board

DG178-F:

Paper-cutting

DG178-K:

Other parts

1 DG178:

3 DG178:

4 DG178:

P4, P5, P6, P7:

P20:

P46:

1

2

3

4

Material list:

Board

1 DG178:

DG178-E:

Paper-cutting

DG178-K:

Mirror

Material list:

Board

1 DG178-E:

DG178-E:

Other parts

1 DG178:

P3:

1

2

Material list:

Board

1 DG178-F:

DG178-G:

Paper-cutting

DG178-K:

DG178-M:

Other parts

1 DG178:

P4:

P8:

1

2

3

4

5

Material list:

Board

1 DG178-G:

DG178-G:

Other parts

1 DG178:

P1:

1

2

3

Material list:

Board

1 DG178-G:

DG178-G:

Other parts

1 DG178:

P1:

1

2

Material list:

Board

1 DG178-G:

DG178-G:

Other parts

1 DG178:

P1:

1

2

Part C

Vase B Sewing machine

Round box C

F7
1:1

P46
1:1

P22
1:1

Part D

Fabric D
Fabric A
Fabric B

Folding box B
Folding box A

Vase A

Part E

Fabric D
Fabric A
Fabric B

Folding box B
Folding box A

Vase A

Part F

Fabric F Fabric G

Fabric H Fabric J

Fabric K

Assembly sequence

Part G

Round box B
Ribbon C
Fabric E

Hat
Hat rack

Part H

Round box A
K19

K17

Part I

Mirror

Dress form

Part J

Storage box A

Part C

Part K

Part E

Square stool

Part L

Part D

Part G

Completion

MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com