Rolife

Fairytale Tree House

— DG179 —



Pictured for reference only. Please subject to the assembly product.

Assembly tips



Put small parts into the bag to prevent loss.



Remove the part by pressing its back to reduce burrs.



Polish the edges with sandpaper if there are burrs on pieces or it 's hard to insert.

Tips of assembling

1. All the dimension in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with ◎)



Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.



Tools required

(The right of the arrow " ⇨ " corresponds with the tool icon.)



Sandpaper | Double-sided tape | Double-sided adhesive dot | Tweezers | Screwdriver | Scissors | Knife

Four-drawer cabinet


Material list:



Low cabinet

Material list:





Step

Material list:



Table

Material list:



Shelf

Material list:

Chair

Material list:

Dice

Material list:

Wardrobe

Material list:

Bed

Material list:



H4
H4
M3
H5
L
M
M7
M
Perspective changed
M
K1
P54
P22
M
H6
N8
H6
H5
M
Ornament
08




Material list:
Board
1 DG179
DG179-G:
G1
G2
G3
Other parts
4 DG179
P23
G1
G2
G3
3 DG179
P23
Use double-sided adhesive dot.
Fireplace
Material list:
Board
1 DG179
DG179-B:
B4
B5
DG179-D:
D10
DG179-G:
G8
2 DG179
P4
P8
Board
1 DG179
DG179-Q:
Q3
Q4
Q5
Paper-cutting
DG179-N
N10
N16
Other parts
5 DG179
P44
P45
P48
P69
Q3
P8 *2
Q4
Q5
P8
N16
N10
09




B5 *4
B4
G8
P4
D10
P69
P48
S
P44
P45
S
Woodpile
Material list:
Board
1 DG179
DG179-D:
D8
Paper-cutting
DG179-N
N9
Other parts
4 DG179
P37
P19
P38
1
P19
L
x2
a
10



2
N9
D8
P37
P38
S
a
S
x6
Bonsai
Material list:
Board
1 DG179
DG179-E:
E15
E16
Paper-cutting
DG179-K
K4
K5
Other parts
4 DG179
P29
P31
P34
5 DG179
P55
P56 *3
P57 *3
1
K4/K5
M
M
P29
E15
P31
E16
2
P55
a
b
P56
P34
Bonsai A
11




3
P56
x2
Complete 2 same parts
M
a
Bonsai B
4
P57
x3
M
b
Bonsai C
Flower
Material list:
Board
1 DG179
DG179-E:
E15
E17
Paper-cutting
DG179-K
K2
K12
K13
4 DG179
P29
P33
Other parts
5 DG179
P53
P60
1
P29
E15
K2
E17
Flower A
12




2
K13
K12
P60
Flower B
3
P53
P33
Flower C
Purple flower
Material list:
Board
1 DG179
DG179-E:
E11
E12
Paper-cutting
DG179-K
K14
K15
Other parts
4 DG179
P30
K14
K15
M
x2
E12
P30
E11
13





Potted plant
Material list:
Board
1 DG179
DG179-E:
E15
Paper-cutting
DG179-K
K3
K8
K9
Other parts
4 DG179
P28
P29
P35
5 DG179
P58
1
P58
P29
E15
Potted plant A
2
K8
P28
K9
Potted plant B
3
K3
P35
Potted plant C
Flower bed
Material list:
Paper-cutting
DG179-M-1
M9
M10
M11
DG179-N
N11
Other parts
5 DG179
P71
1
M9
14




M10
M11
2
P71
N11
b
c
a
a
b
c
Grass
Material list:
Paper-cutting
DG179-M-1
M4
M8
M13
M14
Refer to Flower Bed Step 1
M4
M8
M13
M14
x2
x2
Grass A
Grass B
Grass C
Grass D
Green plant
Material list:
Paper-cutting
DG179-M-1
M12
Other parts
4 DG179
P33
5 DG179
P52
15


P52
1:1
M12
P33
Wind chime
Material list:
Steel bar
Accessories
Other parts
3617A-1
A7
P52
P53



1:1
P52
P53
A7 *3



Staircase
Material list:
Steel
Accessories
Other parts
3617B-1C
A5
P52
1:1


M4*6
1/2
Picture Frame
Material list:
Steel
Accessories
Other parts
3617A-1C
A5
A6
A7
A8
P28*2
1
2
P28
Picture frame A
Picture frame B
Picture frame C
Picture frame D


Part A
Part B
Part C
Bonsai A
Table
Flower
Four-dinner cabinet
Part PH1 in Bag No. 4


Front shell
Material list:
Accessories
Other parts
Package:
P58
M6
M8


Floor plate
Material list:
Steel
3617B-1
3617B-2
Steel
3617A-A
Other parts
P35
P36
P28
P33


2
P28
P33
Floor plate A
Floor plate B
3
Floor plate C

Frame A

Material list:

Wood boards

600MM	300MM	W28
W1	W21	

Screw pack

Package:

S2

Other parts

P31

P36 P42

S1

Floor plate A

W15

Step 1

Step 2

Step 3

P21

Picture frame C

Picture frame B P36

Floor plate B

W16

Picture frame D

Shelf

P42 W

Frame B

Material list:

Wood boards

600MM	300MM	W
W1	W21	

Other parts

P33 P34 P72

P34

Self-prepare "AAA,1.5V(1.5MM 1.5V" batteries.

P33

P33

What if the light can't work?

1. Check if the switch of the battery box is on.
2. Check if the battery box is correctly installed.
3. Check if the wire connection accords with the instructions.

Floor plate C

P33

Assembly sequence A

Wardrobe

Wind chime

Bed

Green plant

Dice

Potted plant B

Flower B

Potted plants

Ornament

Flowers

Stone

K16


K11
K10
Assembly Sequence B
Fireplace



Low cabinet
M2
Part A
Chair


Potted plant B
Part B
Chair



Purple flower
Bonsai B
Part C
Staircase
Bonsai C
Potted plant A


Assembly Sequence C
1:1
Flower bed


Front shell



Grass A
Grass D
Mushroom B
Mushroom C


Step
Woodpile











Completion



MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA

49.1DG179.100