

Musical Instrument Model



WARNING:

- The product is for people who are 8 and up years old. Children who are under 8 years old must assemble under the guidance of adults.

MAINTENANCE:

- Keep the product away from sources of ignition and keep it in dry place in case of the damage.
- Do not use chemical reagents like alcohol, ammonia water, or window cleanser to clean the product.
- Use the sandpaper to polish the blurs after removing the parts from the board if needed.

Email: service@robotime.com

Parts List

Item	Sticker 1	Sticker 2	Sticker 3	String
Number	P1	P2	P3	P4
Illustration				
Quantity	2	2	2	2

*Due to customs policy in international shipping, the wax and glue may not be included. Please prepare them yourself.

Printed side



Special attention in assembly

Blank side



Perspective changed

Step 1

Step 2




ROKR Facebook




store.robotime.com


1



2




B11 is fragile. Assemble carefully.




Assemble in sequence.

3




Pass the string through A3 as shown. Ensure threading strings are of equal length.

Adjust the position of the string and tighten it before assembling B3 and B4.






Complete as shown

Pay attention to the winding grooves during assembly.





After assembly, cut off extra strings.

4






5






P1 & P2 are silver stickers. Paste them according to the outline.







B6 is fragile. Assemble carefully. Pay attention to its direction.



Pay attention to the direction of B6.



6



Suggest to put the fiddlestick B5 as shown.

