

Rolife

BOOK NOOK & WONDERLAND

Magic Fantasy Corner


• TGB14

49.1TGB14.100


Picture is for reference only. Please refer to our existing product.




Assembly Tips



Polish the edges with sandpaper if there are burrs on pieces or it's hard to insert.








Put small parts into the box to prevent loss.





Remove the part by pressing its back to reduce burrs.

1





2




D3

D2




1


G16




3



1





2




F1

D1



TGB14 5-1

P4





P4

D4

D5

D6 x2







E16


3

4



3






5



1















4




6



5



6



7




D19x2

D18

H14

9




D19x2

D18

H14

9



A6

A5


D30





D25

D24















A1





10











9













12










19












14







23










24





15







16








19





Gameplay Instruction





Light test


1. Self-prepare 2 "AAA/LR03/AM4 1.5V" batteries before testing.
- 2.




3.



4.




5.OFF→ON



Light Instruction

Open the door:
Turn on the switch,
and the light is on.

Close the door:
Turn off the switch,
and the light is off.



7.ON→OFF



BOOK NOOK & WONDERLAND

Magic Fantasy
Corner
• TGB14



ROLIFE Facebook



rolife.robotime.com/



TGB06
Garden House



TGB07
Bookstore



TGB09
Floral Corner



TGB11
Sakura Wine Alley



TGB12
Fall into Wonder



TGB13
Street Scene