Rolife

Corner Bookstore

DG164


BOOKS
WITH A BOOK
WELCOME
OPEN
POETRY ROOM
BOOKS & BOOKbinding

Pictures for reference only. Please subject to our existing products.

Rolife

Assembly Tips



Remove the tape from the side with the tip of the tweezers.



Cut off the front and back edges with a knife to remove the part.



Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.



Remove the part by pressing its back to reduce burrs.



Put small parts into the bag to prevent loss.



Polish the edges with sandpaper if there are burrs on pieces or it's hard to insert.

Icon Illustration

Double-sided tape

Printed side

Remove protective film

❗ Special attention in assembly

Blank side

Flip to assemble

Tips of assembling

1.All the dimension in the instruction is shown in millimeter.
2.Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
3.Only the tool icon appears in the assembly step.

Part bag illustration

Bag No.1-2	Plywood, big colored board
Bag No.3	Small colored board
Bag No.4-6	Other parts


1
DG164
Bag number

Rolife

Rolife

Brief Introduction

WARNING:

01. The product requires 2"AAA/LR03/AM4 1.5V" batteries. (Batteries for self-preparation).
02. Before loading or removing batteries, please loosen screws on the cover of the battery box with the screwdriver first.
03. Non-rechargeable batteries are not to be recharged.
04. Rechargeable batteries are only to be charged under adult supervision.
05. Rechargeable batteries are to be removed from the toy before being charged.
06. Different types of batteries or new and used batteries are not to be mixed.
07. Batteries are to be inserted with the correct polarity(+ and -).
08. Remove the exhausted battery in time.
09. The power supply terminal cannot be short circuited.
10. Do not connect the wire to a mains outlet.
11. The product is not to be connected to more than the recommended number of power supplies.
12. Check each part before assembly.If the part is damaged,fix it well before assembly.
13. Please keep the product away from substances flammable and humid environments to prevent damage.
14. The instruction must be retained since it contains important information.

ATTENTION:

1. This product is suitable for people over 14 years old. Children should be guided by adults.
2. This product contains small parts. Please use it carefully to avoid accidental ingestion and room breathing.
3. Please install the electronic components correctly and test whether the circuit is normal after completion.
4. Please read the instructions carefully before assembly to confirm that the parts are not damaged or missing.
5. Please carefully cut the parts and make sure they are firmly pasted when using glue.
6. Some small parts may be embedded in grooves, and please pay attention to checking it.
7. This product needs to be made with auxiliary tools. Please select it reasonably to avoid injury.

Part number illustration

Refer to the part number paper, find the piece and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with Ⓟ)

Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.

Tools required

(The right of the arrow " » " corresponds with the tool icon.)

①



Sandpaper (Bag No.1)

②



Double-sided tape (Bag No.1)

③



Tweezers (Bag No.4)

④



Screwdriver (Bag No.4)

⑤ (Self-preparation)



Scissors

⑥ (Self-preparation)



Knife

⑦ (Self-preparation)



Black pen

Door



Material list:

Board

Tips: 1.Find out parts according to their colors first and then shapes.
2.If there are parts difficult to identify, refer to the part illustration paper in the package.


3
DG164
P1
P2
P3

Paper-cutting


DG164-M-2
M16
OPEN
M17
WELCOME
M19
M18

Other parts


1
DG164
1
2
3
P38
6
DG164
P86


1
DG164
Double-sided tape
P2
P1
P38-3
P86
M16
OPEN
M17
P3
WELCOME
M19
M18

Remove the film on both sides.

Display rack



Material list:

Board


1
DG164
DG164-B:
P33
B1
B2
B3
B4
B5
DG164-C:
C8

Paper-cutting


DG164-K-1
K12
DG164-M-1
M4

Other parts


5
DG164
P67
P68

Rolife


B2
B3
B4
B5
B5
B2


B1
B1
M4
P33
M4
P33
K12
C8
P67
P68

Wall 1



Material list:

Board


1
DG164
DG164-A:
A9
DG164-C:
C4
C5
DG164-D:
D1
D2
D4
D5
D6



Rolife


3
DG164
P4
P5

Paper-cutting


DG164-M-2
Erudite
M20

Other parts


1
DG164
1
2
3
P37
P38


Pay attention to the direction.
Blank side
T1
D6
D6
P38-2
D1
D2
D2
D2


Remove the film on one side.



Rolife


C5
C4
M20
A9
A9
Wall 1

Wall 2



Material list:

Board

1 DG164

DG164-C:



DG164-F:



2 DG164




I2
I3
T2
T3
T5

3 DG164

Paper-cutting

DG164-K-1



Other parts

1 DG164



Rolife


T3
K14
T2
I3
T3
I2
Q1




F2 x4
F1
F1
Pay attention to the direction.
C9
C9

Rolife


P40
1:1
0
1
2
3
0
1
2
3
4
Wall 2

Light



Material list:

Board


1
DG164
P9
P10
DG164-C:
C1
C2
DG164-H:
H4
H5
H6
DG164-D:
D3


3
DG164
P8
P11
P12

Other parts


1
DG164
1
2
3
P38
P36


4
DG164
P41 x2
P42 x2
P43
P44
P45 x2
P46
P47
P48
P49



Rolife

1



Twist the wires together as shown.


P45
P47
1:1
0
1
P42



Light 1





2



Twist the wires together as shown.


P45
1:1
0
1
P42


P43
P44
Rotate to
poke a
hole.

Rolife


P49
P46
C1
Light 2

3


D3
P12
P10
P11


P38-1
P36
H4
H4
H6
H6

Rolife




upper
lower
front
back
P51

Frame 1

Material list:

Board


1
DG164
DG164-G:
G1
G2
G3
G4
G5
G6
G7
G8

Rolife


2
DG164
I1
J2
J1
J3
T4

Paper-cutting

DG164-K-1



DG164-M-2



Other parts





1





Rolife




Display rack
J2


1:1
0
1
2
0
1
2
3
P40
G5
G3
G5
G2
G4



Wrap and stick.


G6
G8
G7
T4
M12







2



Loosen the screw with the screwdriver. (Do not remove it.) Open the back cover. Install 2 "AAA/LR03/AM4 1.5V" batteries. (Batteries for self-preparation.)



Remove the cover of the wire.



Connect the gray to the red wire. Connect the black to the black wire. Wrap insulating tape around the connection of the wires.



Turn on the switch to test the light.

What if the light can't work?

1. Check if the switch of the battery box is on.
2. Check if the battery box is correctly installed.
3. Check if the connection of the light bead is securely welded, and ensure there is no wire breakage.
4. Check if the gray is connected to the red wire, and the black is connected to the black wire.



Close the cover of the battery box, and tighten the screw.

Rolife





Tilt to insert.

Frame 2



Material list:

Board


1
DG164
DG164-A:
A8
DG164-C:
C3
C9
DG164-D:
D9
DG164-H:
H1
H2
Books & Bookbinding
H3


3
DG164
P13
P14
P15
P16
P17
P18
P19

Paper-cutting


DG164-K-1
BOOKS
K1
K10


DG164-M-2
M10
M13
M14
M15
Welcome
M21

Rolife






Special attention in assembly
P15
P18
P13
P14


H1
Round corner
H3
H2





Rolife



Stick tape on the back of D9.


M10
C3
M14
A8


K1
BOOKS
BOOKS
BOOKS
M21

Stick tape on the back of K1.

Bookcase



Material list:

Board

1 DG164 DG164-E:


E1
E1
E1
E2
E2
E3
E3
E4
E4
E5
E5
E6
E6


E2
E3
E4
E6
E1
E1
E5

Table



Material list:

Board


1
DG164
DG164-A:
DG164-C:
DG164-E:
E7
E7
C6
E8
A4
A5
A6
E9
E9
E10
E10
A7
C7

1


A6
A6
A5
A5
E8
E8
E7
A6
E9

Rolife

2


A7
E10
A7
A4
A4
C7
C7
C6
C6

Book box 1



Material list:

Board

1 DG164 DG164-A:


A1
A3
A2
A1
A3


A3
A1
A3
A2
A2

Book box 2



Material list:

Board

1 DG164 DG164-A:


A10
A11
A12
A10
A11
A12

3 DG164




A12
A10
A12
A11
A11
a
b

Assemble b in the same way.

Rolife

Book shelf



Material list:

Board


1
DG164
DG164-B:
B6
B6
B7
B7
B7



Chair



Material list:

Board


1
DG164
DG164-D:
D7
D7
D8
D8

Other parts


5
DG164
P69 x4



Tilt to stick.

Sign



Material list:

Board


1
DG164
DG164-D:
D10
D11
D12

Paper-cutting


DG164-K1
K13





Storage rack



Material list:

Board


3
DG164
P25
P26
P27
P28
P29

Rolife


P25
P28
P28
P26
P26
P27
P29

Storage basket

POETRY ROOM
COME IN

Material list:

Board


1
DG164
DG164-H:
H7

Paper-cutting


DG164-K-1
K9
POETRY ROOM
COME IN
K11

Other parts




K9
K11
H7
POETRY ROOM
COME IN
POETRY ROOM
COME IN

Roll up K9 with the screwdriver.

Grinder

Material list:

Other parts


6
DG164
P72
P73
P74
P75
P76



Rolife

Typewriter

Material list:

Other parts


6
DG164
P77
P78
P79
P80
P81
P82



Potted plant

Material list:

Other parts


5
DG164
P60
P61
P62
P63
P64 x2

Rolife

1


1:1
0
1
2
Potted plant 1

2


Potted plant 2
Potted plant 3

Assemble in the same way.

Potted foliage

Material list:

Other parts


5
DG164
P57
P58
P59
P64 x2
P71

Rolife

1



Potted foliage 1

2



Take off the branches.





Potted foliage 2



Potted foliage 3

Assemble in the same way.

Barrel

Material list:

Other parts

5
DG164

P64



Write "1882" and "ADEG" or other words with a black pen.

Rolife

Telephone

Material list:

Other parts


5
DG164
P55
P66



Twine the white wire with the tip of tweezers (Bag No.4).

Book

Material list:

Board


1
DG164
P28
P30
P31
P32
P33
P34
P35


3
DG164
P23 x5
P24 x3

Paper-cutting

DG164-M-1 DG164-M-2





Book A *2

Rolife



Book B *24


P31
+
BOOK
M3
=
BOOK

Book C *5



Book D *12



Book E *6


P35
+
M9
THE ART OF LANGUAGE
=
THE ART OF LANGUAGE

Book F *24


P23
+
M7
JANE EYRE
=
JANE EYRE

Book G *5



Book H *3

Paper box

Material list:

Paper-cutting


DG164-K-2
K17
K18
K19
K20

Rolife



Follow the steps to fold K17-K20.

Paper box 1

Paper box 2

Paper box 3

Paper box 4

Postbox

Material list:

Paper-cutting


DG164-K-1
POST
K6
K7





Rolife

Copy the arrangement or make a DIY one.

Part A







Part B



Book E *2
Book F *2
Book H *1



Book B *2
Book D *1
Book F *3
Book G *2



Rolife


P63
5
DG164
P54
K3





Part C




Book F *3
P85
6
DG164


Book B *2
Book F *2

Part D







Rolife


K16
Roll up
M11
Wrap and stick with M11.

Book C *1
Book D *3
Book F *2
Book H *1



Part E



Paper box 2



Book E *1
Book F *1



Part F



Book D *1
Book E *1
Book F *2
Book G *2





Rolife

Assembly Sequence


Paper box 1
P16
Book B
Book *5
(A *2,D *3)


Paper box 3, 4
Potted plant 2
Grinder
Book *5
(B *2,C *1,
F *2)


K15
P53
Book B *7
P83

Rolife


1:1
Bend as shown.
P70
0 1 2 3 4 5 6
0 1 2 3 4 5 6
Potted foliage 2
P56
Part E
BOOKS
BLIND DATE WITH A BOOK
OPEN
Books & Bookbinding


Book B *4
Barrel
Part C
Part B
Potted plant 1
BOOKS
BLIND DATE WITH A BOOK
Books & Bookbinding


Part A
Book *7
(F *3,D *2,C *2)
Part F
Telephone
BLIND DATE WITH A BOOK

Rolife


Part D
Sign
Book *5 (B *2,C *1,D *2)
Storage basket
Potted plant 3
Potted foliage 1


Book H
Book E *2
Storage rack
Postbox

BOOKS
BOOKS & BOOKBINDING

Rolife

MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA

49.1DG1[illegible]00.B

Rolife