Rolife

Old Times Bookstore

DP004

Pictures for reference only. Please subject to our existing products.

Assembly tips


Put small parts into the bag to prevent loss.


Remove the part by pressing its back to reduce burrs.


Polish the edges with sandpaper if there are burrs on pieces or it' s hard to insert.

Tips of assembling

1. All the dimension in the instruction is shown in millimeter.
2. The included double-sided tape is an auxiliary tool for sticking. Glue needs self-preparation.
3. Do not stick and peel the double-sided tape repeatedly, considering its initial tack.
4. Only the tool icon appears in the assembly step.
5. Check if the light parts are securely welded.

Part number illustration

Refer to the part number paper, find the piece, and compare it with the 1:1 figure. Then assemble it after confirmation. (Only for wooden pieces marked with ⓟ)



Part list illustration

1. Compare part bags with the part list before assembling to ensure all parts are included.
2. Find the part referring to the part number in the part list, and compare the part with the illustration to ensure it is right before assembling.



Tools required

(The right of the arrow " » " corresponds with the tool icon.)

①
Sandpaper

② 
Double-sided tape

③
Tweezers

④ (Self-preparation)

Scissors

Book cabinet



Material list:

Board


2
DP004
P1
P2
P3
P4
P5
P6
P7

Paper-cutting


DP004-K
K1
K2
K3
K4
DP004-M
M1


P1
M1
P3
P2 *2
P4 *2


1
DP004
S
M
L
P6
P7
M
S
Use double-sided tape


P5
K2
K4
K3
K1

Newspaper rack



Material list:

Board

1 DP004 DP004-A:



Paper-cutting

DP004-K



DP004-M


Art
Manual
Life
Originality
M2

1



2


M
x2
M2 *2
A
S
A
A1
K8
K9



Light



Material list:

Board

1 DP004 DP004-D:





Book shelf



Material list:

Board

1 DP004 DP004-C:


C1
C2
C3
C4
C5
C6

4 DP004



Paper-cutting

DP004-M



Paper-cutting

DP004-K



1



2


M4
C3
C3
M5
C5
M6
C4
C4
C2

3







Umbrella stand



Material list:

Board

1 DP004 DP004-A:



DP004-F:







Book

Material list:

Board


1
DP004
DP004-B:
B4
B5
DP004-E:
E3
E7

Paper-cutting


DP004-M
M7
M8
M9
M10
M11
M12
M13
M14
M15
M16
M17
M18
M19
M20
M21



Book A



Book B


E7
E7
E7
M9
M10
M11

Book C


B5
B5
B5
B5
B5
B5
M12
M13
M14
M15
M16
M17

Book D


B4
B4
B4
B4
M18
M19
M20
M21

Clock & Small sign

Material list:

Board

Paper-cutting


1
DP004
DP004-C:
C7
DP004-D:
2
DP004
D5
P18
DP004-M
M23
M24
M25

1


M23
D5
Clock

2


Printed side
M24
C7
Small sign A

3


M25
P18
Small sign B

Newspaper tube

Material list:

Paper-cutting

Other parts


DP004-K
K11
K12
4
DP004
P36

1



2





Potted plant

Material list:

Other parts


4
DP004
P34
P35



Part A





Part B





Door



Material list:


Board
1 DP004
DP004-B:
B2
2 DP004
P8
P9
Paper-cutting
DP004-M
M26
M27
M28
WELCOME SHOP
EXPLORE WORLD STORIES
Other parts
1 DP004
S3
S4
4 DP004
P33


S4
Remove protective film
S
M26
M27
M28


P9
M
P33
P33
P8 *2



Wall A



Material list:


Board
1 DP004
DP004-F:
F2
2 DP004
P21
P22
P23
Paper-cutting
DP004-M
12 ELM STREET
M30
Other parts
1 DP004
S2
4 DP004
P38


S2
Blank side
L
S
P21
A


F2
P23
P22
S
A



Wall B



Material list:


Board
2 DP004
P13
Paper-cutting
DP004-M
M29
Other parts
1 DP004
S1




BOOK
P13
L
M29

Frame



Material list:


Board
1 DP004
P14
DP004-B:
B1
B3
DP004-E:
E1
E2
E6
DP004-F:
F3

Material list:


Board
2 DP004
P10
P11
P12
P15
P16
P17
Paper-cutting
DP004-M
M22
DP004-K
OLD TIMES BOOKSTORE
BOOK LOVERS' TREASURES
K5
Other parts
4 DP004
P32





2


P10
P11
Book D*4
S
B

3


F3
M22
Wall B
Small sign B
B1
Clock
M
S




P14
P16
P17*2





Rolife


OLD TIMES
Wall A
E2


B3
OLD TIMES

Light & Frame

Material list:


Board
1
DP004
DP004-A:
A8
DP004-C:
C8
DP004-E:
E4
2
DP004
P19
P20
Paper-cutting
DP004-M
M31
DP004-K
K10
Other parts
3
DP004
P27
P29
P30
P31
4
DP004
P37


1
P27
P31
P29
P30
A






Wrap around
3 turns.
K10
S




OLD TIMES
A8
P19
*2
P19
M

Rolife







Photo frame interior

Material list:

Paper-cutting


DP004-K
K16
K17

Other parts


3
DP004
P24
P25
P26
P28

Box :

1



2



Self-prepare "AAA/LR03/AM4 1.5V" batteries.



Touch Test Light is on.

What if the light can't work?

1. Check if the switch of the terminal is on.
2. Check if the battery box is correctly installed.
3. Check if the wire connection accords with the instructions.



Tighten the screws.




How to remove the battery box?





Assembly sequence


Umbrella stand
M
M
Part A


Newspaper tube
S
Potted plant
S


S
Newspaper rack


S
1
E5
DP004-K
K13
S
K13


Light
Small sign A
M








BOOK
K14
DP004-K


Switch on/off

Completion

OLD TIMES
BOOKSTORE
BOOK LOVERS' TREASURES

Series

Fluffy Cat Bakery

DP001

Sweet Scoopery Ice Cream

DP002

Daily Fresh Flower

DP003

Old Times Bookstore

DP004

MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA

49.1DP004.100