DW020

Rolife

熊猫火锅
PANDA HOTPOT
辣
DIPPING SAUCE
PANDA POT
DIPPING SAUCES

SUPER CREATOR | SUPER STORE | Panda Hot Pot

The picture is for reference only.

Assembly Tips



Remove the tape from the side with the tip of the tweezers.



Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.



Push upwards with the tip of the tweezers to remove the floor.



Use the end of the tweezers to remove the connecting nail or assemble small parts.

01 Notice

⚠ WARNING

- Not suitable for children under 3 years old.
- The product shall only be used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is supplied with the product.
- The transformer or power supply is not a toy or model.
- Misuse of transformer can cause electrical shock.
- The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- This product is only to be connected to equipment of Class Ⅱ. ⧈
- Do not connect the wire to the output socket.
- The product is not to be connected to more than the recommended number of power supplies.
- This product doesn't need liquid cleaning, and please clean it with clean soft cloth.
- Please keep the product away from substances flammable and humid environments to prevent damage.
- The instruction must be retained since it contains important information.

02 Icon

Please secure parts as shown in case of any parts loosening:

↓	Use double-sided adhesive dot	▭	Use long-strip adhesive tape
!	Special attention in assembly	⟲	Perspective changed
①	Step 1	②	Step 2
☝	Force point		

03 Switch box instructions（P2）


Control A1, A2
Control B
A1 A2 B

① Switch

Touch switch
(Long press to adjust the brightness.)

② Power on

Type-C interface
Attention! Input power: 5V ⎓ 500mA

04 Data cable instructions（P1）



① Connect to power

Self-preparation

② Multi-house play

05 Assembling steps


01
DW020 1
DW020 3
DW020 2


DW020-M
M1
43.3DW020.001
DW020 2


K1
DW020-K-1
DW020 2
43.3DW020.102




1
2
43.3DW020.004
HOT POT


1
2
(Light part)
43.3DW020.103


02
DW020 5
x2



Assemble in the same way.


03
DW020 5
x2



Rolife


04
DW020 5
x2
K5
K6
05
DW020 5
DW020 4
Transfer sticker
DW020 2
K7


x3
K8
DW020 2
K9
K10
K11
K12
K13


06
DW020 6
x3
2
1
K14
DW020-K-2
DW020 2
07
DW020 6
K15
K16
K17
K18
K19
08
DW020 6


K20
K21
09
DW020 6
K22
K23
10
DW020 6
K24
11
DW020 6
x2
12
DW020 6


M2
13
M3
PANDA


14
15
DW020 7
K25
16
DW020 7
x2


17
DW020 7
18
DW020 7
19
DW020 7
20
DW020 7


21
DW020 8
2
1
22
DW020 8


23
DW020 8
24
DW020 8
25
M4
M5


26
27
DW020 8
X2
28
X26


29
PANDA HOTPOT
30

06 Add some other tricks

Rolife

01 Ceiling light assembly




Under the roof for 1 house
D
Purchase it separately


Under the floor for 2 or more houses


(Connecting part)




Input power:
5V ⎓ 500mA
Cable in the box

02 Dust-proof door assembly


C
Purchase it separately



03 Expand your house kit



MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com