DW027

Rolife

SUPER CREATOR | SUPER STORE | Furry Friends' Home

The picture is for reference only.

Assembly Tips


Remove the tape from the side with the tip of the tweezers.


Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.


Push upwards with the tip of the tweezers to remove the floor.


Use the end of the tweezers to remove the connecting nail or assemble small parts.

01 Notice

WARNING:

- Not suitable for children under 3 years old.
- The product shall only be used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is supplied with the product.
- The transformer or power supply is not a toy or model.
- Misuse of transformer can cause electrical shock.
- The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- Do not connect the wire to output socket.
- The product is not to be connected to more than the recommended number of power supplies.
- If the product contains motor, motor may be a hot component. Do not touch it to avoid burns while operating.
- This product is only to be connected to equipment bearing either of the following symbols: ⧈ or ◈
- This product does not need liquid cleaning, and please clean the product with clean soft cloth.
- The instruction must be retained since it contains important information.

NOTICE:

- Children should be accompanied by adults while assembling.
- Please keep the product away from flammable substances and humid environments to prevent damage.

02 Icon

Please secure parts as shown in case of any parts loosening:

Use double-sided adhesive dot	Use long-strip adhesive tape
! Special attention in assembly	Perspective changed
x2 Complete 2 same parts	Force point
1 Step 1	2 Step 2

03 Switch box instructions (P3)


① Switch
Control A1, A2
Control B
A1
A2
B
② Power-on

Touch switch
(Long press to adjust the brightness.)

Input power supply: 5V ⎓ 500mA
Note: Over-current protection provided, adapters ⩾ 500mA are acceptable.

04 Data cable instructions (P2)

① Connect to power Charger needs self-preparation


Dual Type-C cable
Included in the product
Single-ended Type-C cable
Self-preparation

② Multi-house play[It is recommended that each power supply (not less than 5V 2A) connected to no more than 9 houses.]



05 Assembling steps


DW027
3
DW027
2


DW027
2
43.3DW027.101
DW027
3
K1
DW027-K
DW027
2
43.3DW027.102

Remove useless round parts on the paper.






43.3DW027.104
(Light part)

Please check the following two situations before assembling:


43.3DW027.103






MAIN WELCOME
M1
DW027-M
03
DW027
3
K3
Package


DW027
4
K4
K5




04
DW027
4
DW027
3
DW027
3



Assemble in the same way.


06
YUMMY DOG BITES
M2




YUMMY DOG BITES
M3
07
DOG GRUB
M4


DOG GRUB
M5
M6
M7


08
DW027
5
YUMMY DOG BITES
DOG GRUB
09
DW027
5




K8
10
DW027
3
CAT TEASER
MEOW
K9


CAT TEASER
MEOW
11
DW027
6
K10
DW027
7


x2
12
DW027
5


K11
CANNED CHICKEN
K12
K13
13


CANNED BEEF
14
DW027
6










18
30%
CAN SALE


M9
30%
CAN SALE




20
DW027
6
K14
DW027
7
K15




22
DW027
6
PRICE
HAMSTER HOUSE
M10


23
HAMSTER
M11


24
Deodorant Granules
M12








26
DW027
8
DW027
8

06 Add some other tricks

01 Adjust the position of distribution box and wallpaper.









Rolife

02 Ceiling light assembly


P4
(Light part)

Under the roof for 1 house


D
Purchase it separately

Under the floor for 2 or more houses




(Connecting part)




Cable in the box

Input power supply: 5V ⎓ 500mA
Note: Over-current protection provided, adapters ≥ 500mA are acceptable.

03 Dust-proof doot assembly


C
Purchase it separately



04 Expand your house kit



MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

AFTER-SALES SERVICE CONTACT:
service@robotime.com

49.1DW027.100