Rolife

DW015B

SUPER CREATOR
SUPER CREATOR

The picture is for reference only.

SUPER CREATOR

Assembly Tips



Remove the tape from the side with the tip of the tweezers.



Confirm the position first when sticking the tape on non-flat surfaces, and then remove the film.



Push upwards with the tip of the tweezers to remove the floor.



Use the end of the tweezers to remove the connecting nail or assemble small parts.

Rolife

Rolife

01 Notice

WARNING

- Not suitable for children under 3 years old.
- The product shall only be used with a transformer for product or a power supply for it.
- The product shall be used with the power supply supplied, if the transformer is supplied with the product.
- The transformer or power supply is not a toy or model.
- Misuse of transformer can cause electrical shock.
- The power supply used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.
- Do not connect the wire to the output socket.
- The product is not to be connected to more than the recommended number of power supplies.
- This product doesn't need liquid cleaning, and please clean it with clean soft cloth.
- Please keep the product away from substances flammable and humid environments to prevent damage.
- The instruction must be retained since it contains important information.

02 Icon

Please secure parts as shown in case of any parts loosening:

Use double-sided adhesive dot

Special attention in assembly

Perspective changed

❶ Step 1

❷ Step 2

Force point

03 Switch box instructions

❶ Switch


Touch switch
Control A1, A2
A1
A2
B
Touch switch
Control B
CONTROLLER
CONNECT
TOUCH
Touch switch
(Long press to adjust the brightness.)

❷ Power-on


Type-C interface

Attention! Input power: 5V ⎓ 500mA (MIN)

Power-on suggestions:

1. Use the provided dual Type-C cable to connect to an external Type-C power output port (e.g. power bank).
2. Use a self-provided Type-C cable to connect to an external Type-C power source (e.g. power adapter).
3. This product is only to be connected to equipment of Class Ⅱ. ⧈

---

04 Part list

(Check if there are missing parts. If so, provide customer service with corresponding part names to get the parts.)

SUPER CREATOR

Package

Name	Instruction	Part Bag No.1-7	Connecting part bag	Light part bag	Card paper	Dual Type-C cable	Tweezers
Illustration		 DW015B 1 – DW015B 7	 Connecting part				
Quantity	1	7	1	1	1	1	1

Connecting part

Name	Connecting stick	Connecting nail
Illustration		
Quantity	1	4

Light part

Name	Switch box	Long ceiling light
Illustration		
Quantity	1	1

Bag No.1

Name	P1	Side wall	Back wall	Bottom board	L-shaped stick
Illustration					
Quantity	1	1	1	1	1

Bag No.2

Name	Double-sided adhesive dot (40pcs)	Wallpaper 1	Wallpaper 2	Wallpaper 3	Wallpaper 4	Sticker	Red grid strap	White cloth
Illustra-tion								
Quantity	2	1	1	1	1	1	1	1

Bag No.3

Name	P2
Illustra-tion	
Quantity	1

Bag No.3

Name	P3	P4	P5	P6
Illustra-tion				
Quantity	1	1	1	1

Bag No.4

Name	Transfer sticker	Decorative cover	P7	P8	P9	P10
Illustra-tion						
Quantity	1	4	3	1	1	1

Bag No.4

Name	P11	P12	P13	P14	P15	P16	P17	P18	P19	P20
Illustra-tion										
Quantity	1	1	1	1	1	1	1	1	1	1

Bag No.5

Name	P21	P22	P23	P24	P25
Illustra-tion					
Quantity	1	1	2	2	2

Bag No.5

Name	P26	P27	P28	P29	P30	P31
Illustra-tion						
Quantity	4	2	1	2	4	2

Bag No.5

Name	P32	P33	P34	P35	P36	P37	P38	P39	P40	P41	P42
Illustra-tion											
Quantity	2	1	1	1	1	1	1	1	1	2	1

Bag No.5

Name	P43	P44	Dome sticker
Illustra-tion			
Quantity	1	1	1

Bag No.6

Name	P45	P46	P47	P48
Illustra-tion				
Quantity	1	2	1	1

Bag No.6

Name	P49	P50	P51
Illustra-tion			
Quantity	1	2	2

Rolife

Bag No.6

Name	P52	P53	P54	P55	P56	P57	P58
Illustration							
Quantity	4	2	1	1	1	1	2

Bag No.7

Name	P59	P60	P61	P62	P63
Illustration					
Quantity	3	3	6	1	4

Bag No.7

Name	P64	P65	P66	P67	P68	P69	P70	P71	P72	P73
Illustration										
Quantity	1	1	1	2	1	1	1	1	1	1

Bag No.7

Name	P74	P75	P76	P77	P78	P79	P80	P81	P82	P83	P84
Illustration											
Quantity	1	1	1	1	2	1	1	1	1	1	1

05 Assembling steps




Bottom
(DW015B 2)

Align with the groove to adjust the wire direction.

Double-sided adhesive dot



Align to assemble.




K1
(DW015B-K) Sticker (DW015B 2)

Put against the edge.







Ensure no other parts are between them.

Rolife


GOLDEN OLDIES
(DW015B 4)
The non-number side faces upwards.


GOLDEN OLDIES

04





05




Fold in half.
Stick
(Reverse side)
M1
(DW015B-M)Card paper
M2
With The Trend
Stay With The Trend
N&W SUMMER BEACH

M2 Assemble in the same way.

06





07







Align with the groove.

You can press against a table.

Rolife




Press in by tweezers.

Assemble M4 in the same way.




(DW015B
4)
Blank side
Blank side

Note the floor pattern direction.

You can adjust the layout according to the wallpaper“ ”, so the wires are longer for flexible arrangement.


43.DW015B.101
Remove
(DW015B
2)
43.DW015B.102

Remove the paper to expose holes.





Stick double-sided adhesive dot.


43.DW015B.103
43.DW015B.104

Pass through the middle hole.

Face up

(Light part)

Avoid the wire covering holes and assemble.

See “03 Switch box instructions” on Page 1.

If you choose to combine it with another house, skip this step.



(Find it in the smaller bag.)

2 Slide and align with the upper hole.

1 Tilt to align with the lower hole.



2 Slide and align with the upper hole.

1 Tilt to align with the lower hole.





Align

Align with the groove.

Secured part illustration

Rotate carefully counterclockwise.
If it’ s hard to rotate, push upwards
to make it protrude and rotate to secure.









Rolife










(Find it in the smaller bag.)


② Slide and align with the upper hole.

① Tilt to align with the lower hole.

(Find it in the smaller bag.)









The sticker has low tack in a low-temperature environment, and easily curls up on the curved surface.
You can use double-sided tape to secure.










DW015B
2
Cloth bottom

Stick 2 double-sided adhesive dots on each side.

Press securely by tweezers and remove the protective film.

Rolife



Pinch to make shapes.













The sticker has low tack in a low-temperature environment, and easily curls up on the curved surface.
You can use double-sided tape to secure.



Rolife




Don’ t put reversely.

Assemble in the same way.












Cover the rim to avoid the part falling off.


26
DW015B
7
x3







Rolife

06 Add some other tricks

Rolife

01 Ceiling light assembly




Assembly method 1 (Under the roof for 1 house)
A
B
C
Purchase it separately (See assembly instructions of the roof.)


Assembly method 2
(Under the floor for 2 or more houses)
Take out the part.
Insert


(Connecting part)
Take out the part.


Face up
1
2
Connect to Control B.


Cable in the box
Input power:
5V⎓500mA (MIN)

Rolife

02 Dust-proof door assembly



Purchase it separately





Purchase it separately

Dust-proof Door b has been replaced by Dust-proof Door c.



Rolife

03 Expand your house kit


Take out the part.



MANUFACTURER:
Robotime C&C (Jiangsu) Co., Ltd.

ADDRESS:
28 Wenzhou Road, Shuyang, Suqian, Jiangsu, China

ROLIFE SUPER CREATOR

Rolife

49.DW015B.100