ROWOOD

Paris Cathedral

TG511

Picture is for reference only. Please refer to our existing product.

Assembly Tips

Polish the edges with sandpaper if there are burrs on pieces or it' s hard to insert.

Put small parts into the box to prevent loss.

Remove the part by pressing its back to reduce burrs.

3
D1
D2
C8
D4
D5
F19 x6
C25
11

F20 x6
C24
d
F5
F6
12

F7 x2
Assemble with the "TOOL" in the Board F.
TIPS
D18
D19
C3
D11
x2
13

C5 x2
D10 x2
4
e
D14 x5
C9
D7
D6
14

D8
D8
e
D17 x2
1
2
D15
D16 x2
15

f
5
F12 x4
C18
F15
f
1
2
3
C22
16

F15
1
2
C21
F15
F13 x4
C19
F14
C23
F14
17

C20
F14
C17
1
2
F2
F1
2
F3 x4
18

F4
F8 x2
F9 x2
F11
F10 x2
C4
C26
19

D3
D3
D12 x2
D12 x2
D13
D13
B21 x5
B22 x5
20

Designed by ROBOTIME
www.robotime.com
MADE IN CHINA

49.1TG511.100